

1. Unpack the monitor, antenna and the data/power cable. The 25-pin connector plugs onto the front of the OmniMetrix® monitor. This cable includes wires to power the monitor as well as wires for alarm inputs, relay outputs and analog inputs. Take a moment to inspect all components to verify there is no shipping damage.
2. Place the antenna vertically on the roof of the generator and route the antenna cable into the area of the generator control. The antenna used for transmitting must be installed to provide a separation distance of at least 20 cm from all persons and must not transmit simultaneously with any other antenna transmitters. BE SURE to provide a drip loop lower than the monitor to keep water from running down the antenna cable into the monitor connection.
3. Attach the monitor via its magnetic feet, on top of the engine controller or other appropriate location. Horizontal surfaces are best, but the unit may be mounted vertically or even upside down if necessary. *Note: If mounted vertically, install the monitor with the cables down to prevent water from entering the enclosure.*
4. Route the data/power cable into the generator control enclosure.
5. Instructions for wiring the monitor can be found in the table on the following page.
6. Attach the antenna cable to the front of the monitor, and tighten thumb tight.
7. Turn on the monitor and confirm that the LEDs light up and blink. If not, check for power on the terminal strip. If, after 5 minutes, the only LED lit is the Power LED, check the antenna mount and cable connection.
8. Allow 15 minutes for the monitor to log into the network and then call OmniMetrix at 770-209-0012 to confirm installation. Access to machine data is through the OmniView™ web interface at [www.omnimetrix.net](http://www.omnimetrix.net). Contact OmniMetrix for login instructions and web training.



Data/Power Cable



MEC 20 Controller

TrueGuard-PRO MEC 20 Wiring Table		
OMN WIRE	FUNCTION	TERMINATION
Red	Battery +	B+
Black	Battery -	B-
Orange	Generator Running	19
Blue	Common Alarm	27
Pink	Not in Auto	30
Brown	Generator Supplying Load	33
Tan	Oil Pressure Low	36
Gray	Coolant Temp High	20
White\Yellow	Remote Start\Stop	16
White\Brown	Remote Start\Stop	17
Alarm Grounds	Customer to wire terminals 26, 29, 32, 35, & 21 to Control Panel B- or Ground	

**MEC 20 Wiring Table**

Alarms require programming using Thompson Technology Software and communication cable. Customer is responsible for having proper software and connection cables at time of install. The above Thompson Technology Alarms are the standard alarms selected by OmniMetrix. See the Thompson Technology MEC2/20 Control Panel Manual for further information.

**If you have any questions, please call OmniMetrix Tech Support at 770-209-0012 or email at [techsupport@omnimetrix.net](mailto:techsupport@omnimetrix.net).**